

# RAW2 说明书 规格：233x415mm 70g白纸

## 正面


## 背面




### RAW2<sup>®</sup> 智能骑行头盔 使用说明书

#### 一、产品介绍：

感谢您选择 Anytek 头盔。此头盔不仅具有行车安全保护功能，同时具有记录仪、照明、警示灯功能。守护您安全的同时，也将带给您全新的科技感体验。下面是此头盔的功能介绍及正确使用方法。




#### 二、产品功能及按键：




#### 三、使用方法：


1. 记录功能：短按录像开机键（如图），蓝灯闪烁开始录像。长按开机键（如图）蓝灯熄灭关闭录像。



4. 尾灯警示功能：短按尾灯键（如图尾灯中间按键），尾灯依次慢闪—快闪—长亮—熄灭循环。




7. 边充边录：此设备有边充边录功能，在充电的同时，可以同步开启记录仪（侧面）功能。



8. 时间修改：打开TF卡里自动生成time文件。按里面格式直接修改成现在时间并保存。录像时间即生成所需时间。

#### 四、佩戴方法：



1. 购买前请测量好自己的头围，选择适合自己的尺寸的头盔；  
2. 请水平佩戴头盔，不可过度前倾和后仰。将头围大小调节带调到不易滑动和舒适为佳；  
3. 调整头盔两侧织带交叉的位置，使其处于双耳的中间，扣紧织带，防止行驶中脱落；  
4. 头盔应放置于阴凉通风处，防止受潮发霉；  
5. 正确佩戴运动头盔能有效降低运动伤害，但不能完全避免伤害。

#### 五、产品详细参数：

型号	RAW2
存储介质	TF卡 (Option) 最大支持128G
视频格式	AVI
像素分辨率	1980*1080
摄像角度	广角130度
电池	1200mAh
充电时长	5H
录像时长	12H
雷达照明	30流明
数据线	TYPE-C
固件	支持升级
系统软件	支持升级
配件	说明书* 数据线*1、保修卡*1

#### 六、注意事项：

- 收到头盔后，请确认通电后再开机。充电或暂时不使用时，请关闭尾灯。
- 头盔电子模块部分在正确佩戴的情况下，具有一定的防水功能，但不建议下雨时使用。或者下雨时请及时在头盔上覆盖防水头盔套。
- 若头盔内有雨滴或不慎落入，请放置通风处吹干，待干燥后再次使用。
- 在极低天气或者零度下，电池寿命会受到影响。
- 不得更改头盔结构。
- 头盔可用清水清洗，切不可用酒精、汽油等有机溶剂或强酸等腐蚀性液体清洗。
- 如头盔受到大力撞击或有破损，请停止使用。



#### 七、保修条例

- 质保细则  
1. 以下若有与国家政策不符或遗漏之处，以国家政策为准；  
2. 本产品自购买之日起因产品质量问题免费保修一年，在确保商品完好的情况下15天内包换；  
3. 本公司对产品的其他配置（例如包装及赠品等）不承担质保责任。
- 保修说明  
您的保修服务仅限于正常使用有效，非本产品本身质量问题造成的损坏及属下列情况之一产品，不实行质保，但可以实行收费修理：  
1. 超过质保有效期；  
2. 无质保凭证及有效发票的，但能证明该产品在质保有效期内的除外；  
3. 质保凭证上的内容与商品实物不符或者涂改的；  
4. 非原厂配件或私自拆卸、维修、保养而造成的损坏；  
5. 非本公司授权的维修店擅自造成损坏的；  
6. 因不可抗力造成的损坏；  
7. 产品自然磨损（例如：外壳、按键、油漆、油渍、附件等）；  
8. 非本公司原因造成的故障、缺陷或瑕疵。

#### 八、电子功能故障排除

在使用过程中，如果出现以下功能异常，请检查TF卡安装是否正确或损坏，也可进行复位操作（请阅读说明书中的“复位”章节），如果故障无法排除，请联系售后服务中心。

- 无法正常开机或充电；
- 开机时，录像等功能异常或无法使用；
- 开机后较短时间内出现自动关机

#### 警示


- 产品内含有电池，请不要将废弃的产品和一般生活垃圾放在一起，回收处理废旧电池有法规的地区，请遵循当地管理部门的有关规定，为环保贡献一份力量；
- 产品内含有电池，不可将产品投入火中，也不可将其放置于高温场所，以免电池漏液、过热、爆裂或起火；
- 产品内含有电池，严禁拆卸、挤压、加热或焚烧电池，严禁使用尖锐物、螺丝刀等刺破、撬电池，以上操作可能会导致电池起火或爆炸；
- 产品内含有电池，充电时，由于电池温度会升高，请不要将产品和易燃物放在一起（如：床、衣物、书本等），以免发生火灾。

#### 九、保养说明

- 头盔表面的污垢，请用中性洗涤剂清洗，不要使用开水、汽油和天那水等腐蚀性物质。挡风镜上的污垢先用清水冲洗再用软布抹净
- 内衬清洗或头盔内部被雨水、汗水沾湿后，应放在阴凉处晾干。
- 严禁在头盔壳体上开孔或修改内部结构，以防损害其防震和抗穿透作用，不要撞击头盔
- 切勿将头盔放在车辆挂钩或暴晒在阳光下，从而降低了头盔的安全性

#### 头盔适用的使用条件说明


- A类头盔适用于燃油或电动摩托车驾乘以及电动自行车驾乘
- B类头盔仅适用于电动自行车驾乘
- 12岁以下的儿童应选择质量较轻的头盔




### RAW2<sup>®</sup> SMART HELMET RECORDING WHILE RIDING INSTRUCTION MANUAL

#### 1.Product introduction:

Thank you for choosing Anytek helmet, this helmet not only has the function of driving safety protection, but also has the functions of recorder, lighting and alert light. While protecting your safety, it will also bring you a new sense of technology experience. The following is an introduction to the functions of this helmet and how to use it correctly.




#### 2.Product functions and buttons:




#### 3.Ways to use:


1. Recorder function: short press the recording power button (as shown), the blue light flashes to start recording. Press and hold the power button (as shown), the blue light and the recording will be turned off.



4. Taillight alert function: short press the taillight button (as shown), the taillight flashes slowly in sequence - fast flash - long bright - extinguished cycle.




7. Recording while charging: This device has the function of recording while charging. While charging, the recorder (as shown) function can be turned on at the same time.



8. Time modification: Open the time file automatically generated in the TF card. Modify it directly to the current time according to the format inside and save it. The recording time can generate the required time.

#### 4.Ways to wear:




- Please measure your head circumference before purchasing a helmet and choose a helmet that suits your head size.
- Please wear the helmet horizontally, do not lean forward and backward too much, and adjust the head circumference size adjuster to be less prone to shaking and comfortable.
- Adjust the position of the webbing bifurcation buckles on both sides of the helmet so that the ears are in the middle of the webbing, and fasten the buckles to prevent them from falling off during driving.
- If raindrops accidentally fall into the helmet, please place it in a ventilated place to dry, and use it again after drying.
- Wearing a sports helmet correctly can effectively reduce sports injuries, but it cannot completely prevent them.

#### 5.Product details:

Model	RAW2
Storage medium	TF Card (Option) Max support to 128G
Video Format	AVI
Video Resolution	1980*1080
Camera angle	Wide angle 130 degrees
Battery	1200mAh
Charging time	5H
Recording Time	12H
Headlight lighting	30LM
Data Cable	TYPE-C
Firmware	Support upgrade
System software	Support upgrade
Accessories	Manual*1/TYPE-C*1/Warranty Card*1

#### 6.Matters needing attention:

- After receiving the helmet, please make sure it is fully charged before turning it on. When charging or temporarily not in use, please turn off the front and rear lights.
- The electronic module part of the helmet has a certain waterproof function when it is properly worn, but it is not recommended to use it when it is raining or when it rains, please cover the helmet with a waterproof hood in time.
- If raindrops accidentally fall into the helmet, please place it in a ventilated place to dry, and use it again after drying.
- In extremely low weather or freezing temperatures, battery life can be affected.
- The structure of the helmet must not be altered.
- The helmet can be wiped with clean water, but must not be wiped with organic solvents such as alcohol, gasoline, or corrosive liquids such as acid and alkali.
- If the helmet is hit hard or damaged, please stop using it.



#### 7.Warranty Regulations:

- If there is any inconsistency or omission with the national policy, the national policy shall prevail.
- This product is guaranteed for one year free of charge due to product quality problems from the date of purchase, and is repaired within 5 days under the condition that the product is in good condition.
- The company is not responsible for other configurations of the product (such as packaging and gifts, etc.)
- Warranty Description  
Your warranty service is only valid under normal use, damage not caused by the quality of the product itself and one of the following conditions: No warranty, but can be repaired for a fee  
1. Exceeded the warranty period  
2. Without warranty certificate and valid invoice, except for those that can prove that the product is within the validity period of warranty  
3. The content on the warranty certificate does not match the actual product or is altered  
4. Damage caused by force majeure  
5. Damage caused by dismantling by a service shop not authorized by the company  
6. Damage caused by fire or burn  
7. Natural wear and tear of the product (eg. case, keys, paint, accessories, etc.)  
8. Failure, defect or defect not caused by our company

#### 8.Troubleshooting of electronic functions

During use, if the following abnormality occurs, please check whether the TF card is installed correctly or damaged, or reset it (please use thumb or toothpick, etc. to reset), if the fault cannot be eliminated, please contact the after-sales service center

- Cannot turn on or charge normally
- When the machine is turned on, the camera and other functions are abnormal or cannot be used.
- Automatic shutdown occurs within a short period of time after startup

#### Warning

- The product contains batteries, please do not put the discarded products and general household waste together. Please follow the relevant regulations of the local management department and contribute to environmental protection.
- The product contains a battery. Do not put the product into fire or place it in a high temperature place to prevent the battery from leaking, overheating, bursting or fire.
- The product contains batteries. It is strictly forbidden to disassemble, squeeze, heat or burn the battery. It is strictly forbidden to use sharp objects, screwdrivers, etc. to puncture or pry the battery. Operation may cause the battery to catch fire or burn.
- The product contains a battery. When charging, because the battery temperature will rise, please do not put the product and flammable objects together (such as: bedside, clothing, books, etc.) to avoid fire.

#### 九、Maintenance instructions

- Please use a neutral detergent to clean the dirt on the surface of the helmet, and do not use corrosive substances such as boiling water, salt water, gasoline, and thinner. Wash the dirt on the windshield with water first and then wipe it off with a soft cloth
- After cleaning the interior of the helmet or getting wet with rainwater or sweat, it should be placed in a cool place to dry
- It is forbidden to make holes on the helmet shell or modify the internal foam layer to prevent damage to its shock resistance and penetration resistance. Do not hit the helmet.
- Do not put the helmet on the vehicle hook or expose it to the sun, thus reducing the safety of the helmet

#### Instructions for the applicable usage conditions of helmets

- Class A helmets are suitable for fuel or electric motorcycle occupants as well as electric bicycle occupants
- Class B helmets are limited to electric bicycle occupants only
- Children under 12 years old should choose lightweight helmets